



# Advanced Visual CO<sub>2</sub> Sensor For Space Habitation

Wyatt Bush | Dr. Lei Zhang, Dept. Mechanical Engineering | Dr. Ataur Chowdhury, Dept. Physics | Dr. Bill Simpson, Dept. Chemistry and Biochemistry | ASG Undergraduate Summer Fellowship Program

## Project Overview



Monitoring CO<sub>2</sub> levels in space habitation is crucial for astronaut safety. The upper bound for regular CO<sub>2</sub> levels in a room is 1000ppm (0.1%). 5000ppm (0.5%) is the upper bound for loss of attention, increased heart rate, nausea, headaches, and sleepiness. Any concentration greater than 40,000ppm (4%) leads to death or serious brain damage. Human breath consists of about 4% CO<sub>2</sub>.

Current methods employ expensive electronics that take up valuable storage space and must be monitored, so storage and cost is an issue in space habitation. We propose to develop a less expensive, more convenient, and long lasting CO<sub>2</sub> color-changing coating that changes color in increasing levels of CO<sub>2</sub> which takes up virtually no storage.

We hope to see the coating in paints or on wearables such as bracelets and clothing so astronauts will be alerted earlier by seeing a color change on their person instead of constantly monitoring electrical equipment.

## Variables / Equations

Glycerol	Base	Indicator
<ul style="list-style-type: none"><li>Plasticizer used to make polymers softer. Glycerol in the coating helps retain water for the CO<sub>2</sub> acid-base reaction.</li><li>Used as sweetener, food preservative, or as lubricants.</li></ul>	<ul style="list-style-type: none"><li>Sodium bicarbonate (SB) is a weak base, carbonic acid buffer, and makes the color change reversible.</li><li>TBAH is a strong base and is an alternative base to sodium bicarbonate.</li></ul>	<ul style="list-style-type: none"><li>Acid-base indicator used for color change in a pH range.</li><li>Ideally pKa of indicator should match pH of base for quick color change and increased sensitivity.</li></ul>
Carbonic Anhydrase	Albumin Protein	Other
<ul style="list-style-type: none"><li>One of the most important enzymes in the human body.</li><li>Catalyzes the reaction of CO<sub>2</sub> in water to form acid which is transported from red blood cells to the lungs and then reversed back to CO<sub>2</sub> to be released when exhaling.</li></ul>	<ul style="list-style-type: none"><li>Albumin is the main protein found in chicken egg whites.</li><li>Promotes diffusion of CO<sub>2</sub> through aqueous solutions.</li><li>Albumin is in human blood and acts as a carrier for the transport of ions, vitamins, and enzymes.</li></ul>	<ul style="list-style-type: none"><li>HEC Polymer – cosmetics, compatibility</li><li>Coating thickness – thin gives greater diffusion.</li><li>Pressure – limiting agent. Fractions of an atmosphere.</li><li>Humidity – moisture improves sensitivity.</li><li>Hydrophobic solvent – like dissolves like.</li></ul>





## Materials/Procedure


Materials (Trial #8)	Quantity
Carbonic Anhydrase	0.04 g
Store Bought Egg Whites	None
Glycerol	4.18 g
Sodium Bicarbonate (0.6M)	2.0 mL

Materials (Trial #9)	Quantity
Carbonic Anhydrase	0.036 g
Store Bought Egg Whites	2.5 mL
Glycerol	4.08 g
Sodium Bicarbonate (0.6M)	2.0 mL

Materials (Trial #30)	Quantity
Carbonic Anhydrase	0.030 g
Albumin Powder	0.007 g
Glycerol	3.67 g
TBAH (0.1M)	0.7 mL (14 drops)



## Results



- Trial #8 using sodium bicarbonate is responsive to gas and not breath. Slower recovery time than initial trials. Enzyme but no protein. Little change 4 months later.
- Trial #9 using sodium bicarbonate shows sensitivity and color change from breath. Slower recovery time than initial trials. Enzyme and protein. Breath effect stops after 1 week. Discoloration and breath effect failure due to perishable egg whites, still shows good responsiveness 4 months later.
- Trial #30 using TBAH and albumin powder is slightly less responsive than trial #9 and slightly greater recovery time. Is responsive to breath, but takes more exhaling. Less water in coating than trials #8 and #9 due to TBAH drops. Ongoing study for breath effect lifetime.

## Conclusion

- Trials showed improved sensitivity when using albumin and carbonic anhydrase at higher levels of glycerol. Glycerol softens the polymer and increases hydration allowing for greater diffusion of CO<sub>2</sub>.
- High glycerol levels impair use as solid coating due to a greater liquid phase than solid phase. More study is needed to perfect solid to liquid phase ratios.
- Limited CO<sub>2</sub> pressures, buffers, low humidity, and a less hydrophobic medium contribute to decreased sensitivity. Alcohol based solvents or heat destroy and inhibit the enzyme and protein activity.
- Options for increasing sensitivity include changing indicator to transition in near neutral pH to add less base. Greater enzyme or protein quantities, more hydrophobic solvents, polymers or plasticizers, and switching bases.

## Acknowledgments

- I would like to thank Alaska Space Grant for their funding and support of this project.
- I also would like to thank Dr. Zhang for her additional funding and support of the project, Dr. Andrew Mills at Queen's University Belfast for meeting with me and keeping correspondence regarding his research, and Dr. Chowdhury and Dr. Simpson for their help into the spectroscopy aspects of the project.

## Works Cited

- Mills, Andrew, and Graham A. Skinner. "Water-Based Colourimetric Optical Indicators for the Detection of Carbon Dioxide." *The Analyst*, vol. 135, no. 8, 2010, p. 1912., doi:10.1039/c000688b.
- Gros, Gerolf, et al. "Facilitated Diffusion of CO<sub>2</sub> across Albumin Solutions." *JGP*, Rockefeller University Press, 1 Sept. 1974, jgp.rupress.org/content/64/3/356.